

Navigation: [Home](#) => [Profil](#) => SeaTalk
Stand: 10.10.2002



SeaTalk Technical Reference

Revision 3.02

General Information

SeaTalk is a simple interface for networking [Raymarine/Autohelm](#) marine equipment so that all devices of a ship can exchange and share their data. SeaTalk is a proprietary solution of Autohelm and **not** compatible with NMEA or CAN. Unfortunately Raymarine keeps the technical details of SeaTalk secret. To assist users who want to develop hard- or software to connect their devices to the SeaTalk bus these pages uncover some of the mysteries. Part 3 adds hints how to interface SeaTalk with a PC. The information is unsupported by Raymarine and was found by watching the bits travelling on the bus. Therefore the description is incomplete inaccurate and may even be wrong. [Corrections and contributions](#) are welcome.

Content

The technical description of the SeaTalk protocol is divided into three parts:

1. [Part 1: How SeaTalk works](#)
 - a. [Hardware-Interface](#) describes the function of the three SeaTalk wires
 - b. [Serial Data Transmission](#) describes the parameters of the asynchron serial port
 - c. [Composition of Messages](#) describes the structure of datagrams
 - d. [Collision Management](#) describes the arbitration between simultaneous talkers
 - e. [Data Coding](#) describes common rules for coding numerical values
2. [Part 2: Recognized Datagrams](#) describes the SeaTalk messages and their meaning
3. [Part 3: Processing SeaTalk Data with a PC](#)
 - a. [Circuit example for an unidirectional SeaTalk => PC interface](#)
 - b. [Circuit example for a bidirectional SeaTalk <=> PC interface](#)
 - c. [Simple SeaTalk monitoring utility for download](#)
 - d. [SeaSigma: A small SeaTalk command generator for download](#)

Revision History:

Rev 3.02: [October 2002] Timer command 59 added thx Frank Wallenwein
Rev 3.01: [August 2002] Link added in Acknowledgement to Jon Fick's remote control project
Rev 3.00: [August 2002] Splits the information into parts 1-3 and includes the [SeaSigma](#) utility
Rev 2.20: [March 2002] Some additions to part 2 thx Harald Sammer
Rev 2.19: Minor additions for autopilot Vane Mode (command 84)
Rev 2.18: Minor corrections to datagrams 0x85 and 0x26
Rev 2.17: Many additions to part 2 thx Harald Sammer
Rev 2.16: Link added to Acknowledgement

Rev 2.15: Minor additions / corrections to part 2

Rev 2.14: MOB-commands 36 and 6E added to part

Acknowledgement

Many thanks to

Knut Wiren, Finland

[Mikael Wahlgren](#), Sweden (developed a PIC-based SeaTalk remote control)

Reiner Patommel, Danmark

Arnold de Maa, Holland

[Wouter van Ooijen](#), Netherlands (developed a PIC-based SeaTalk protocol converter)

[Jürgen Saniter](#), Germany (developed a SX-28 based SeaTalk remote control)

Harald Sammer, Scotland

Ales Janhar, Slovenija (developed the SeaSigma utility)

[Jon Fick](#), USA (developed another PIC-based remote control) and

[Frank Wallenwein](#), Germany

who contributed valuable information for this page.

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part 1
Stand: 28.08.2002



SeaTalk Technical Reference Part 1: How SeaTalk works

Hardware-Interface

SeaTalk uses three wires, connected in parallel to all devices on the bus:

1. +12V Supply, red
2. GND Supply, grey
3. Data Serial Data, yellow: +12V=Idle/Mark=1, 0V=Space/Data=0, 4800 Baud, pullup circuit in each device, talker pulls down to 0V (wired OR). For [connection to a RS232 receiver](#) voltage levels must be inverted.

Serial Data Transmission

11 bits are transmitted for each character:

- 1 Start bit (0V)
- 8 Data Bits (least significant bit transmitted first)
- 1 Command bit, set on the first character of each datagram. Reflected in the parity bit of most UARTs. Not compatible with NMEA0183 but well suited for the multiprocessor communications mode of 8051-family microcontrollers (bit SM2 in SCON set).
- 1 Stop bit (+12V)

Composition of Messages

Each datagram contains between 3 and 18 characters:

1. Type of command (the only byte with the command-bit set)
2. Attribute Character, specifying the total length of the datagram in the least significant nibble:

Most significant 4 bits: 0 or part of a data value

Least significant 4 bits: Number of additional data bytes = n =>

Total length of datagram = 3 + n characters

3. First, mandatory data byte
4. - 18. optional, additional data bytes

No datagrams or devices carry addresses. This eliminates the need for an initialization or arbitration phase on the bus. Events (such as a keystroke) are published as soon as they occur. Measured data is repeatedly transferred, typically about once per second. So the

current values are always available to all devices on the bus and there is no need (and no way) to request a particular information.

Collision Management

There is no master on the bus. Every device has equal rights and is allowed to talk as soon as it recognizes the bus to be idle (+12V for at least 10/4800 seconds). Low priority messages use a longer or randomly selected idle-bus-waiting-time. This allows messages from other devices with a higher priority to be transmitted first. The different waiting times of all devices make data collisions (two or more devices start talking at exactly the same moment) very rare. Since each device also listens to its own transmission it will recognize when its message is garbled by a second talker. In this case it abandons the remaining characters of the datagram. It waits for the bus to become free again and then retransmits the whole message. For listeners this means that messages which are shorter than expected are invalid and have to be cancelled totally.

Data Coding

Some characters are repeated with all bits inverted for noise or transmission error detection. Example: 0xA2 is followed by 0x5D. The sum of both bytes must always be 0xFF. The listing below shows repeated bytes in small letters (example: ZZ zz).

Numerical values are transmitted binary coded and with least significant data first. Example: 0x13 0x57 means $0x5713 = 22291$

Some values are put together by certain bits of a byte or nibble. The meaningful bits can be isolated by a bitwise AND operation (&). Example: (U & 0x3) filters the least significant two bits of U.

The "distance to destination" value (ZZZ in command 0x85) uses a scaling factor of 1/10 or 1/100 nm depending on the shift indicator bit (LSBit of Y).

[Return to Top of Page](#) [Overview](#) [Part 2](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part2
 Stand: 10.10.2002



SeaTalk Technical Reference Part 2:

Recognized Datagrams (in hexadecimal notation):

Com Att Dat Dat...

00	02	YZ	XX	XX	Depth below transducer: XXXX/10 feet Display units: Y=0 => feet, Y=4 => meter Flags: Z&1 Shallow Depth Alarm (Z=1) Z&2 Transducer defective (Z=4) Corresponding NMEA sentences: DPT, DBT
01	05	00	00	00	60 01 00 Sent by course computer 400G shortly after power on.
01	05	FA	03	00	30 07 03 Sent by ST80 Maxi Display shortly after power on.
01	05	04	BA	20	28 01 00 Sent by ST60 Tridata shortly after power on
10	01	XX	YY	Apparent Wind Angle: XXYY/2 degrees right of bow Used for autopilots Vane Mode (WindTrim) Corresponding NMEA sentence: MWV	
11	01	XX	0Y	Apparent Wind Speed: (XX & 0x7F) + Y/10 Knots Units flag: XX&0x80=0 => Display value in Knots XX&0x80=0x80 => Display value in Meter/Second Corresponding NMEA sentence: MWV	
20	01	XX	XX	Speed through water: XXXX/10 Knots Corresponding NMEA sentence: VHW	
21	02	XX	XX	0X Trip Mileage: XXXXX/100 nautical miles	
22	02	XX	XX	00 Total Mileage: XXXX/10 nautical miles	
23	41	XX	YY	Water temperature (ST50): XX deg Celsius, YY deg Fahrenheit Corresponding NMEA sentence: MTW	
24	02	00	00	XX Display units for Mileage & Speed XX: 00=nm/knots, 06=sm/mpg, 86=km/kmh	
25	Z4	XX	YY	UU VV AW Total & Trip Log total= (XX+YY*256+Z* 4096)/ 10 [max=104857.5] nautical miles trip = (UU+VV*256+W*65536)/100 [max=10485.75] nautical miles	
26	04	XX	XX	YY YY D1 Speed through water: Sensor 1: XXXX/100 Knots, valid if D1&64=64 Sensor 2: YYYY/100 Knots, valid if D1&128=128 Corresponding NMEA sentence: VHW	
27	01	XX	XX	Water temperature: (XXXX-100)/10 deg Celsius Corresponding NMEA sentence: MTW	
30	00	0X		Set lamp Intensity; X=0: L0, X=4: L1, X=8: L2, X=C: L3 (only sent once when setting the lamp intensity)	

36 00 01 Cancel MOB (Man Over Board) condition

38 X1 YY yy Codelock data

50 A2 XX YY YY LAT position: XX degrees, (YYYY & 0x7FFF)/100 minutes
MSB of Y = YYYY & 0x8000 = South if set, North if cleared
Corresponding NMEA sentences: RMC, GAA, GLL

51 A2 XX YY YY LON position: XX degrees, (YYYY & 0x7FFF)/100 minutes
MSB of Y = YYYY & 0x8000 = East if set, West if cleared
Corresponding NMEA sentences: RMC, GAA, GLL

52 01 XX XX Speed over Ground: XXXX/10 Knots
Corresponding NMEA sentences: RMC, VTG

53 X0 XX Course Magnetic: XXX/8 Degrees
Least significant 2 bits are always 0,
giving a resolution of 0.5 degrees
Corresponding NMEA sentences: RMC, VTG

54 S1 SS HH GMT-time: HH hours, SSS seconds
Corresponding NMEA sentences: RMC, GAA, BWR, BWC

55 X1 YY yy TRACK keystroke on GPS unit
keycodes identical with autopilot ([command 86](#))

56 M1 DD YY Date: YY year, M month, DD day in month
Corresponding NMEA sentence: RMC

57 S0 DD Sat Info: S number of sats, DD horiz. dillution of position
Corresponding NMEA sentences: GGA, GSA

58 Z5 LA XX YY LO QQ RR LAT/LON
LA Degrees LAT, LO Degrees LON
minutes LAT = XX*256+YY
minutes LON = QQ*256+RR
Z&1: South (Z&1 = 0: North)
Z&2: East (Z&2 = 0: West)
Corresponding NMEA sentences: RMC, GAA, GLL

59 22 SS MM XH Set Count Down Timer
MM=Minutes (00..3B) (00 .. 63 Min), MSB:0 Count up start flag
SS=Seconds (00..3B) (00 .. 59 Sec)
H=Heures (0..9) (00 .. 09 Heures)
X= Counter Mode: 0 Count up and start if MSB of MM set
4 Count down
8 Count down and start
(Example 59 22 3B 3B 49 -> Set Countdown Timer to 9.59:59)

59 22 0A 00 80 Sent by ST60 in countdown mode when counted down to 10 Seconds.

6C 05 04 BA 20 28 2D 2D Second datagram sent by ST60 Tridata shortly after power on

6E 07 00 00 00 00 00 00 00 00 MOB (Man Over Board), (ST80), preceded by a Waypoint 999 command: 82 A5 40 BF 92 6D 24 DB

80 00 0X Set Lamp Intensity: X=0 off, X=4: 1, X=8: 2, X=C: 3

81 01 00 00 Sent by course computer during setup when going past USER CAL.
81 00 00 Sent by course computer immediately after above.

82 05 XX xx YY yy ZZ zz Target waypoint name
XX+xx = YY+yy = ZZ+zz = FF (allows error detection)
Takes the last 4 chars of name, assumes upper case only
Char= ASCII-Char - 0x30

$XX \& 0x3F$: char1
 $(YY \& 0xF) * 4 + (XX \& 0xC) / 64$: char2
 $(ZZ \& 0x3) * 16 + (YY \& 0xF0) / 16$: char3
 $(ZZ \& 0xFC) / 4$: char4
 Corresponding NMEA sentences: RMB, APB, BWR, BWC

83 07 XX 00 00 00 00 00 80 00 00 Sent by course computer.
 XX = 0 after clearing a failure condition, also sent once after
 power-up.

XX = 1 failure, auto release error. Repeated once per second.

84 U6 VW XY OZ 00 RR SS TT Compass heading Autopilot course and
 Rudder position (see also command 9C)

Compass heading in degrees:

The two lower bits of $U * 90 +$
 the six lower bits of $VW * 2 +$
 the two higher bits of $U / 2 =$
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 8$

Autopilot course in degrees:

The two higher bits of $V * 90 + XY / 2$

$Z \& 0x2 = 0$: Autopilot in Standby-Mode

$Z \& 0x2 = 2$: Autopilot in Auto-Mode

$Z \& 0x4 = 4$: Autopilot in Vane Mode (WindTrim), requires regular

"10" datagrams

Rudder position: RR degrees (positive values steer right,
 negative values steer left. Example: $0xFE = 2^\circ$ left)

$SS \& 0x01$: when set, turns off heading display on 600R control.

$SS \& 0x02$: always on with 400G

$SS \& 0x08$: displays "NO DATA" on 600R

$SS \& 0x10$: displays "LARGE XTE" on 600R

$SS \& 0x80$: Displays "Auto Rel" on 600R

TT : Always $0x08$ on 400G computer

85 X6 XX VU ZW ZZ YF 00 yf Navigation to waypoint information

Cross Track Error: XXX/100 nautical miles

Example: X-track error 2.61nm => 261 dec => $0x105$ => $X6XX=5_10$

Bearing to destination: $(U \& 0x3) * 90^\circ + WV / 2^\circ$

Example: GPS course $230^\circ = 180 + 50 = 2 * 90 + 0x64 / 2$ => $VUZW=42_6$

$U \& 8 = 8$ -> Bearing is true, $U \& 8 = 0$ -> Bearing is magnetic

Distance to destination: Distance 0-9.99nm: $ZZZ / 100nm$, $Y \& 1 = 1$

Distance $\geq 10.0nm$: $ZZZ / 10 nm$, $Y \& 1 = 0$

Direction to steer: if $Y \& 4 = 4$ Steer right to correct error

if $Y \& 4 = 0$ Steer left to correct error

Example: Distance = 5.13nm, steer left: $5.13 * 100 = 513 = 0x201$ =>

ZW ZZ YF=1_ 20 1_

Distance = 51.3nm, steer left: $51.3 * 10 = 513 = 0x201$ =>

ZW ZZ YF=1_ 20 0_

Track control mode:

F= $0x1$: Display x-track error and Autopilot course

F= $0x3$: Enter Track Control Mode, i.e. lock on to GPS.

Display x-track error, autopilot course and bearing
to destination

F= $0x5$: Display x-track error, distance to waypoint,

autopilot course and bearing to destination

normal--> F= $0x7$: Enter Track Control Mode, i.e. lock on to GPS.

Display x-track error, distance to waypoint,

autopilot course and bearing to destination

F= $0xF$: As $0x7$ but with x-track error alarm

F= 2, 4, 6, 8 ... causes data errors

Corresponding NMEA sentences: RMB, APB, BWR, BWC, XTE

86 X1 YY yy Keystroke

X=1: Sent by Z101 remote control to increment/decrement
course of autopilot

11 05 FA -1

11 06 F9 -10

11 07 F8 +1

11 08 F7 +10

11 20 DF +1 & -1

```

11 21 DE -1 & -10
11 22 DD +1 & +10
11 28 D7 +10 & -10
11 45 BA -1 pressed longer than 1 second
11 46 B9 -10 pressed longer than 1 second
11 47 B8 +1 pressed longer than 1 second
11 48 B7 +10 pressed longer than 1 second
11 60 DF +1 & -1 pressed longer than 1 second
11 61 9E -1 & -10 pressed longer than 1 second
11 62 9D +1 & +10 pressed longer than 1 second
11 64 9B +10 & -10 pressed longer than 1 second (why not 11 68 97 ?)

```

Sent by autopilot (X=0: ST 1000+, X=2: ST4000+ or ST600R)

```

X1 01 FE Auto
X1 02 FD Standby
X1 03 FC Track
X1 04 FB disp (in display mode or page in auto chapter = advance)
X1 05 FA -1 (in auto mode)
X1 06 F9 -10 (in auto mode)
X1 07 F8 +1 (in auto mode)
X1 08 F7 +10 (in auto mode)
X1 09 F6 -1 (in resp or rudder gain mode)
X1 0A F5 +1 (in resp or rudder gain mode)
X1 21 DE -1 & -10 (port tack, doesn't work on ST600R?)
X1 22 DD +1 & +10 (stb tack)
X1 23 DC Standby & Auto (wind mode)
X1 28 D7 +10 & -10 (in auto mode)
X1 2E D1 +1 & -1 (Response Display)
X1 41 BE Auto pressed longer
X1 42 BD Standby pressed longer
X1 43 BC Track pressed longer
X1 44 BB Disp pressed longer
X1 45 BA -1 pressed longer (in auto mode)
X1 46 B9 -10 pressed longer (in auto mode)
X1 47 B8 +1 pressed longer (in auto mode)
X1 48 B7 +10 pressed longer (in auto mode)
X1 63 9C Standby & Auto pressed longer (previous wind angle)
X1 68 97 +10 & -10 pressed longer (in auto mode)
X1 6E 91 +1 & -1 pressed longer (Rudder Gain Display)
X1 80 7F -1 pressed (repeated 1x per second)
X1 81 7E +1 pressed (repeated 1x per second)
X1 82 7D -10 pressed (repeated 1x per second)
X1 83 7C +10 pressed (repeated 1x per second)
X1 84 7B +1, -1, +10 or -10 released

```

```

87 00 0X Set Response level
X=1 Response level 1: Automatic Deadband
X=2 Response level 2: Minimum Deadband

```

```

88 03 WW XX YY ZZ Autopilot Parameter: Sent by AP every
second while in parameter setting mode.
(User or Dealer Calibration Mode)
WW Parameter Number
XX Current Setting
YY Max Parameter Value
ZZ Min Parameter Value
Known Paramters: Parameter (min-max) [default]

```

Number

- 1 rudder gain (1-9) [2]
- 2 counter rudder (1-9) [2]
- 3 rudder limit (10-40) [30]
- 4 turn rate limit (1-30) [off]
- 5 speed (4-60) [8]
- off course limit (15-40) [20]

6 auto trim (0-4) [1]
 7 power steer [Joy Stick] ON/OFF (not on new 400G)
 9 drive type (3,4,5) [3]
 A rudder damping (1-9) [2]
 B variation: (full degrees)(-30 to +30) [0]
 C auto adapt: 0=Off,1=North,2=South [1]
 D auto adapt latitude (0-80) [0]
 E auto release (only for stern drive) ON/OFF
 F rudder alignment (-7 to +7) [0]
 10 Wind Trim (Wind Response) (1-9) [5] (only for sail)
 11 Response (1-9) [5]
 12 Boat type:1=displ,2=semi-displ,3=plan,4=stern,5=work,6=sail
 13 Cal Lock: 0=OFF, 1=ON [0]
 15 Auto Tack Angle (40-125) [100] (only for sail)
 1d

89 U2 VW XY 2Z Compass heading sent by ST40 compass instrument
 (it is read as a compass heading by the ST1000(+) or ST2000(+)
 autopilot)

Compass heading in degrees:

The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 the two higher bits of U / 2 =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 2$

Locked stear reference (only send by the ST40 compass):

The two higher bits of V * 90 + XY / 2

Z & 0x2 = 0 : St40 in Standby mode

Z & 0x2 = 2 : St40 in Locked stear mode

Corresponding NMEA sentences: HDM, HDG, HDT, VHW

90 00 XX Device Identification
 XX=02 sent by ST600R ~every 2 secs
 XX=05 sent by type 400G course computer
 XX=A3 sent by NMEA <-> SeaTalk bridge ~every 10 secs

91 00 0X Set Rudder gain to X

92 02 XX YY 00 Set Autopilot Parameter: Sent by the remote head
 (e.g. ST600R) to set a particular parameter.
 XX Parameter Number (see 88)
 YY Value to set to.

93 00 00 Enter AP-Setup: Sent by course computer before
 finally entering the dealer setup. It is repeated
 once per second, and times out after ten seconds.
 While this is being sent, command 86 X1 68 97 is
 needed for final entry into Setup. (600R generates
 this when -1 & +1 are pressed simultaneously in this
 mode).

95 U6 VW XY 0Z 00 RR 00 0T Replaces command 84 while autopilot is in value
 setting mode
 e.g. lamp intensity or response level

99 00 XX Compass variation sent by ST40 compass instrument
 or ST1000, ST2000, ST4000+ autopilot every 10 seconds
 but only if the variation is set on the instrument
 Positive XX values: Variation West, Negative XX values:
 Variation East
 west ...
 Examples (XX => variation): 00 => 0, 01 => -1 west, 02 => -2
 FF => +1 east, FE => +2 east ...
 Corresponding NMEA sentences: RMC, HDG

9A 09 L11 L12 L13 L14 L21 L22 L23 00 00 00 Version String:
 L11 means line 1 char 1. There are two lines, line 1
 Can have 4 characters and line two can have 3
 Characters. Char: "A"= 0x00, "B"= 0x01,.....
 Char: "0"= 0x25, "1"= 0x26,
 Some special characters are mapped to the range
 Between alphas and numeric chars. It seems modulo
 masked at 0x36, and wraps around from there.

9C U1 VW RR Compass heading and Rudder position (see also command 84)
 Compass heading in degrees:
 The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 the two higher bits of U / 2 =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 8$
 Rudder position: RR degrees (positive values steer right,
 negative values steer left. Example: 0xFE = 2° left)
 The rudder angle bar on the ST600R uses this record

9E FC 49 49 03 XX AA BB YY OO PP GG HH II JJ Waypoint definition
 XX: Degrees LAT, YY: Degrees LON
 min&sec LAT= AA+(BB&0x1F)*256, BB&0x80 = 0: North, BB&0x80 = 0x80:
 South
 East
 min&sec LON= OO+(PP&0x1F)*256, PP&0x80 = 0: West, PP&0x80 = 0x80:
 GG HH II JJ: Last four characters of waypoint name

A1 XD 49 49 GG HH II JJ C1 C2 C3 C4 C5 C6 C7 C8 Destination Waypoint Info
 GG HH II JJ: Last four characters of waypoint name
 C1...C8: Up to 8 characters of WP name, unused are 0
 Longer names (> 8 chars) create an additional record:
 X=0: single record (short name)
 X=1: 1st record, more follows
 X=3: last record
 Corresponding NMEA sentences: RMB, APB, BWR, BWC

A2 X4 00 00 00 00 00 Arrival Info
 X&0x2=Arrival perpendicular passed, X&0x4=Arrival circle entered
 Corresponding NMEA sentences: APB, AAM

A5 GPS and DGPS Info

A5 57 QQ HH ?? AA GG ZZ YY DD GPS and DGPS Fix Info
 Signal Quality= QQ&0xF, QQ&0x10: Signal Quality available flag
 HDOP= HH&0x7C, HH&0x80: HDOP available flag
 Antenna Height= AA
 Number of Sats= (QQ&0xE0)/16+(HH&0x1), HH&0x2: NumSats available
 flag
 GeoSeperation= GG*16 (-2048....+2047 meters)
 Differential age=(ZZ&0xE0)/2+(YY&0xF), YY&0x10: Diff. age
 available flag
 Differential Station ID=(YY&0xC0)*4+DD, YY&0x20: Diff.St.ID
 available flag
 Corresponding NMEA sentences: GGA, RMC, GSV, GLL, GGA

A5 74 ID ID ID ID ID GPS Info: ID numbers of satellites
 A5 XD NN AA EE SS MM BB FF GG OO CC DD XX YY ZZ GPS Info: Sat Position and
 Signal

```
Data of up to three satellites [1,2,3] per datagram
Satellite number: [1] NN&0xFE, [2] (MM&0x70)/2+(BB&0x7), [3]
CC&0x3F
Satellite azimuth:[1] AA*2+(EE&0x1), [2] (BB&0xF8)*2+(FF&0xF), [3]
(CC&0xC0)*2+DD&0x7F
Satellite elevation:[1] (EE&0xFE)/2, [2] (FF&0xF0)/2+GG&0x7, [3]
XX&0x7F
Satellite signal: [1] (SS&0xFE)/2, [2] (GG&0x80)/2+OO&0x3F, [3]
(YY&0xFC)/2+ZZ&0x1
```

It seems that there will be 4 sat info datagrams generated, the first with X=0 carries the position and signal data of the 1st 3 satellites. The second also with X=0, but NN&0x1 set and a length of 0x0C carries the data of the next 2 satellites and then the ID numbers of the 1st 4 sats. A datagram like the 1st one, but with X=2 carries data of 3 more sats [6,7,8]. It was not possible to get more than 8 sats mapped to SeaTalk. Finally a datagram with X=7 carries the next 5 ID numbers.

Corresponding NMEA sentences: GSV, GSA


[Return to Top of Page](#) [Overview](#) [Part 1](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part3
 Stand: 28.08.2002

SeaTalk Technical Reference Part 3: Processing SeaTalk Data with a PC


Unidirectional SeaTalk => RS232 Interface

This simple unidirectional interface circuit inverts the SeaTalk signal to make it readable by the PC serial port:



Bidirectional SeaTalk <=> RS232 Interface

For bidirectional communication the circuit has to be extended by a second transistor:



SeaTalk Monitor

The following piece of C-code gives an example of how to collect and process SeaTalk data. It monitors the SeaTalk bus and echoes the SeaTalk datagrams in hexadecimal notation to the screen.

```
#include <stdio.h>

/* Set Address of Serial Port: COM1=0x3F8, COM2=0x2F8 */
#define PORT 0x3F8

unsigned int collision_ctr, overrun_ctr;
char buffer[256], in_ptr, out_ptr, limit_ptr;
char line_status_reg, receiver_buf, byte_ctr;
char hex[]="0123456789ABCDEF";

main() {
    puts("SeaTalk Monitor Rev. 1.01      (c)2000 by Thomas Knauf\r\n");

    /* Serial Port Initialization */
    _outb( 0, PORT+1); /*IER Disable Interrupts */
    _outb( 1, PORT+2); /*FCR Enable Fifo */
    _outb(0x80, PORT+3); /*LCR Enable access to Divisor Latch */
    _outb( 24, PORT ); /*DLL Set Baud Rate to 4800 LSB*/
    _outb( 0, PORT+1); /*DLM Baud Rate Divisor MSB */
    _outb(0x3B, PORT+3); /*LCR Stick Parity to 0, Enable Parity, 1 Stop bit, 8 bits/char
*/
    _outb(0x0F, PORT+4); /*MCR Disable LOOP Mode */
    _outb( 0, PORT+5); /*LSR Clear Error flags */

    while(1) { /* Continous data processing loop */
        if((line_status_reg= _inb(PORT+5)) & 1) { /* LSR New SeaTalk Data received ? */
            receiver_buf=_inb(PORT); /* RBR Read SeaTalk Data Byte */
            if(line_status_reg & 2) overrun_ctr++; /* PC too slow, should not happen */
            if(line_status_reg & 4) { /* Parity bit set => Command Byte */
                if(byte_ctr) { /* More characters expected => Collision */
                    in_ptr=limit_ptr; /* Discard last datagram, restart from beginning */
                    collision_ctr++; /* Count collision events */
                }
                buffer[in_ptr++]='\r'; /* Put new command on new line */
                buffer[in_ptr++]='\n';
                byte_ctr=255; /* Undefined datagram length, wait for next character
*/
            } else
                if(byte_ctr==254) /* Attribute byte ? */
                    byte_ctr=(receiver_buf & 0xF) + 2; /* Read expected datagram length */
            if(byte_ctr) { /* Process valid data bytes, should always be true */
                buffer[in_ptr++]=hex[receiver_buf >> 4]; /* Convert Data to hex */
                buffer[in_ptr++]=hex[receiver_buf & 0xF];
                buffer[in_ptr++]=' '; /* Seperate by space */
                if(! --byte_ctr) limit_ptr=in_ptr; /* Complete datagram ready for
output */
            }
        } else
            if(out_ptr != limit_ptr) /* Characters waiting for Output ? */
                putchar(buffer[out_ptr++], stdout); /* Copy single character from buffer to screen
*/
            else if(scr_csts()) break; /* Query keyboard, terminate if any key hit */
    }
    printf("\r\nSeataalk Collisions : %5u", collision_ctr);
    printf("\r\nUART Overrun Errors: %5u", overrun_ctr);
}
```

Compiled EXE-Files can be downloaded here as [SEAMON1.EXE](#) (using COM1:) or

[SEAMON2.EXE](#) (using COM2:). They run in any MS-DOS environment. Redirecting the output logs data to a file (example: SEAMON1 > LOGFILE). Pressing any key terminates the program.

SeaSigma: A simple SeaTalk command generator

The file [SeaSigma.zip](#) contains a MS-Windows program which allows to generate SeaTalk commands and to send them via COM1: or COM2: to the SeaTalk bus. Since SeaSigma is a contribution of [Ales Janhar](#) I cannot give support or take any responsibility for this software.

[Return to Top of Page](#) [Overview](#) [Part 1](#) [Part 2](#)